



900 Rock Avenue, San Jose, CA 95131, USA

# JLink LTE

User Manual

Version 1.1  
Last revised July 31, 2018



All contents in this manual are copyrighted by JAVAD GNSS. All rights reserved. The information contained herein may not be used, accessed, copied, stored, displayed, sold, modified, published, or distributed, or otherwise reproduced without express written consent from JAVAD GNSS.

# PREFACE

**T**hank you for purchasing this product. The materials available in this Manual (the “Manual”) have been prepared by JAVAD GNSS, Inc. (“JAVAD GNSS”) for owners of JAVAD GNSS products. It is designed to assist owners with the use of JLink LTE and its use is subject to these terms and conditions (the “Terms and Conditions”). Please read these Terms and Conditions carefully.

## **Terms and Conditions**

**USE** – JAVAD GNSS products are designed to be used by a professional. The user is expected to have a good knowledge and understanding of the user and safety instructions before operating, inspecting or adjusting. Always wear the required protectors (safety shoes, helmet, etc.) when operating the unit.

**COPYRIGHT** – All information contained in this Manual is the intellectual property of, and copyrighted material of JAVAD GNSS. All rights are reserved. You may not use, access, copy, store, display, create derivative works of, sell, modify, publish, distribute, or allow any third party access to, any graphics, content, information or data in this Manual without JAVAD GNSS’ express written consent and may only use such information for the care and operation of your JLink LTE. The information and data in this Manual are a valuable asset of JAVAD GNSS and are developed by the expenditure of considerable work, time and money, and are the result of original selection, coordination and arrangement by JAVAD GNSS.

**TRADEMARKS** – JLink LTE™, JAVAD GNSS® are trademarks or registered trademarks of JAVAD GNSS. Windows® is a registered trademark of Microsoft Corporation; Bluetooth® word mark is owned by the Bluetooth SIG, Inc. Product and company names mentioned herein may be trademarks of their respective owners.

**DISCLAIMER OF WARRANTY** – EXCEPT FOR ANY WARRANTIES IN THIS MANUAL OR A WARRANTY CARD ACCOMPANYING THE PRODUCT, THIS MANUAL AND JLINK LTE ARE PROVIDED “AS-IS.” THERE ARE NO OTHER WARRANTIES. JAVAD GNSS DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE OR PURPOSE. JAVAD GNSS AND ITS DISTRIBUTORS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN; NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL OR THE JLINK LTE. SUCH DISCLAIMED DAMAGES INCLUDE BUT ARE NOT LIMITED TO LOSS OF TIME, LOSS OR DESTRUCTION OF DATA, LOSS OF PROFIT, SAVINGS OR REVENUE, OR LOSS OF THE PRODUCT’S USE. IN ADDITION, JAVAD GNSS IS NOT RESPONSIBLE OR LIABLE FOR DAMAGES OR COSTS INCURRED IN CONNECTION WITH OBTAINING SUBSTITUTE PRODUCTS OR SOFTWARE, CLAIMS BY OTHERS, INCONVENIENCE, OR ANY OTHER COSTS. IN ANY EVENT, JAVAD GNSS SHALL HAVE NO LIABILITY FOR DAMAGES OR OTHER-

WISE TO YOU OR ANY OTHER PERSON OR ENTITY IN EXCESS OF THE PURCHASE PRICE FOR JLink LTE.

**LICENSE AGREEMENT** – Use of any computer programs or software supplied by JAVAD GNSS or downloaded from a JAVAD GNSS website (the “Software”) in connection with JLink LTE constitutes acceptance of these Terms and Conditions in this Manual and an agreement to abide by these Terms and Conditions. The user is granted a personal, non-exclusive, non-transferable license to use such Software under the terms stated herein and in any case only with a single JLink LTE or single computer. You may not assign or transfer the Software or this license without the express written consent of JAVAD GNSS. This license is effective until terminated. You may terminate the license at any time by destroying the Software and Manual. JAVAD GNSS may terminate the license if you fail to comply with any of the Terms or Conditions. You agree to destroy the Software and manual upon termination of your use of JLink LTE. All ownership, copyright and other intellectual property rights in and to the Software belong to JAVAD GNSS. If these license terms are not acceptable, return any unused software and manual.

**CONFIDENTIALITY** – This Manual, its contents and the Software (collectively, the “Confidential Information”) are the confidential and proprietary information of JAVAD GNSS. You agree to treat JAVAD GNSS’ Confidential Information with a degree of care no less stringent than the degree of care you would use in safeguarding your own most valuable trade secrets. Nothing in this paragraph shall restrict you from disclosing Confidential Information to your employees as may be necessary or appropriate to operate or care for JLink LTE. Such employees must also keep the Confidentiality Information confidential.

In the event you become legally compelled to disclose any of the Confidential Information, you shall give JAVAD GNSS immediate notice so that it may seek a protective order or other appropriate remedy.

**WEBSITE; OTHER STATEMENTS** – No statement contained at the JAVAD GNSS website (or any other website) or in any other advertisements or JAVAD GNSS literature or made by an employee or independent contractor of JAVAD GNSS modifies these Terms and Conditions (including the Software license, warranty and limitation of liability).

**SAFETY** – Improper use of JLink LTE can lead to injury to persons or property and/or malfunction of the product. The JLink LTE should only be repaired by authorized JAVAD GNSS warranty service centers. Users should review and heed the safety warnings.

**MISCELLANEOUS** – The above Terms and Conditions may be amended, modified, superseded, or canceled, at any time by JAVAD GNSS. The above Terms and Conditions will be governed by, and construed in accordance with, the laws of the State of California, without reference to conflict of laws.

## **Regulatory Information**

The following sections provide information on this product’s compliance with government regulations.

### **FCC Class B Compliance**

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television equipment reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Move the equipment away from the JLink LTE.

Plug the equipment into an outlet on a circuit different from that to which the unit is powered.

Consult the dealer or an experienced radio/television technician for additional suggestions.

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void your authority to operate such equipment.

### **Canadian Emissions Labeling Requirements**

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### **WEEE Directive**

The following information is for EU-member states only: The use of the symbol indicates that this product may not be treated as household waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the take-back and recycling of this product, please contact your supplier where you purchased the product or consult.



### **Screen Captures**

This manual includes sample screen captures. Your actual screen can look slightly different from the sample screen due to the unit you have connected, operating system used and settings you have specified. This is normal and not a cause for concern.

### **Technical Assistance**

If you have a problem and cannot find the information you need in the product documentation, contact your local dealer. Alternatively, request technical support using the JAVAD GNSS World Wide Web site at: [www.javad.com](http://www.javad.com)

To contact JAVAD GNSS Customer Support use the QUESTIONS button available on the [www.javad.com](http://www.javad.com).

# DESCRIPTION AND OPERATION

JLink LTE is a family of devices designed for organizing a local network between different devices via WiFi, Ethernet, and Bluetooth, connecting to the Internet using 4G cellular digital communication services.

JLink LTE provides a robust solution linking the field GNSS equipment to RTN, where no cell phone cover is available. JLink LTE devices may contain 1 W either UHF (406 to 470 MHz) or VHF (138-174 MHz), or ISM license free USA band (902-928 MHz) and European CEPT license free (868-870 MHz) radio trans-

ceiver. Marine Radiobeacon receiver (283.5 to 325 kHz) can be built-in into JLink LTE device.

JLink LTE can be configured and supported using web-interface through Internet, and this makes the setup mechanism simple and accessible from anywhere in the world.

## JLink LTE LED Functionality

The table below describes the LED indicators and device state:

LED	Symbol	Device State					
		External Power ON			External Power OFF		
POWER/BAT		BAT Charged	BAT Half	BAT Empty	BAT Full	BAT Half	BAT Empty
					BLINK	BLINK	BLINK
UHF		TR and RX	TX	Error	RX	TX	
		SEARCH			LOW RSSI (< -90 dBm) (BLINK)	LOW OUTPUT POWER (<20dBm) (BLINK)	
					MIDDLE RSSI (-90 .. -50dBm) (BLINK)	MIDDLE OUTPUT POWER(20..27dBm) (BLINK)	
					HIGH RSSI (> -50 dBm) (BLINK)	HIGH OUTPUT POWER(27dBm) (BLINK)	
GSM				Error	Active		
		REGISTRATION			2G (BLINK)		
		2G			3G (BLINK)		
		3G			4G (BLINK)		
		4G					
BT/WIFI		BT		WIFI			
				Client		Access Point	
		Error	Active	Error	Active	Error	Active
			BLINK		BLINK		BLINK

LED indication

## Installation

1. Connect Bluetooth and GSM antennas to JLink LTE as shown on the picture below.
2. Connect JLink LTE to external power supply (10...30 V).
3. Insert SIM card to the SIM card slot and SD card to the SD card slot.



Figure 1. Card installation

4. Plug in LAN cable if you would like to use Ethernet connection to connect to Internet.
5. Plug in COM PORT cable if you would like to use CLI interface to communicate with device.

### Setup and Configuration

1. Turn on power of JLink LTE.
2. Wait for complete loading. When it is complete, Power LED will blink.
3. Connect to the device and configure it using web-browser.

Connection can be established in one of the following ways:

- via Bluetooth interface: the device (PC, handheld/pad) should be with Bluetooth interface with PAN profile support. JLink LTE Bluetooth-interface is in visibility mode, has the name “Jlink LTE” and PIN code 0000. When connection is established open the web-browser and enter the address 10.1.11.1:8080.
- via WiFi interface: The device (PC, handheld/pad) should be with WiFi interface.

JLink LTE WiFi-interface has the name “Jlink LTE” and password “testtest”. When connection is established open the web-browser and enter the address 10.1.10.1:8080.

- via Ethernet: JLink LTE LAN static IP address is 192.168.0.200 and network mask is 255.255.255.0. On the PC connected to the same LAN, open the web browser and enter the address 192.168.0.200:8080. The dialog window appears with login/password request. Enter login and password (jlink/jlink).




Figure 2. Login and password entering

Thereafter the device is ready for setup and configuration.

4. Select the interface which will be used to connect to Internet and configure it. The following interfaces are available:

Ethernet: Configure Ethernet interface in the Communication/LAN tab. Set the network parameters and reboot the device using Reboot button in the Administration/Management tab see figure below.




Figure 3. LAN configuration tab

**GSM/LTE/4G:** Configure this interface using Communication/GSM tab. Set the APN parameters (if necessary) and select the SIM-card slot. In the Communication/Power Management tab activate the interface and wait for registering in the network and Internet access availability. More detailed connection status you can check in Status/GSM tab see below.




Figure 4. GSM configuration tab

**WiFi client:** In the Communication/WiFi it is necessary to switch the interface to the client mode. In the Communication/Power Management tab turn the WiFi interface on. Select the network you would like to connect in the Communication/WiFi tab, enter password to get access and wait for the connection see below. More detailed connection status you can check in Status/WiFi tab.




Figure 5. WiFi client configuration tab

**Access to Serial port via Network:** In the Communication/Advanced tab it is necessary to select Serial port as Console (see figure below) and reboot device from Administration/Management or do power cycle. After reboot the device is ready for connection to serial port CLI interface with username “jlink” password “jLTEXXXXX” where “XXXXX” is serial number of device which is written in device label. For connecting to JLink LTE serial port needed to setup with following parameters:

- Baudrate 115200
- Parity none
- Data Bits 8
- Stop Bits 1
- Handshake hardware

# How to...

## ...Setup JLink LTE to provide RTK data received via NTRIP Client to Serial Port

The following are the steps of configuration of JLink LTE:

1. Connect to JLink LTE via web interface as described above.
2. Configure the Cellular (GSM):

In the Communication/GSM tab set the PIN code and APN parameters (if necessary);




Figure 6. Advanced configuration tab

- Access to Serial port via Network:

In the Communication/Advanced tab it is necessary to select Serial port as Network (see figure below) and reboot device from Administration/Management or do power cycle.

After reboot device is ready for telnet connection to serial port using “Ser2Net” as login and “jlinklte” as password. For connecting to JLink LTE serial port needed to setup with following parameters:

- Baudrate 115200
- Parity none
- Data Bits 8
- Stop Bits 1
- Handshake hardware




Figure 8. JLink LTE GSM configuration tab

Use tweezers to install or remove micro SIM card.

Insert the SIM card to its slot. The first slot from the green top cover is for micro SIM, the second slot is for micro SD.

In the Communication/Power Management tab activate the GSM interface.




Figure 7. Advanced configuration tab




Figure 9. JLink LTE Power Management tab

Wait for registering in the network and Internet access availability . Detailed connection status you can check in Status/GSM tab.




Figure 10. JLink LTE GSM Status tab

It is possible also to connect JLink LTE to Internet via LAN or WiFi using any WiFi router, MiFi device or even smart-phone configured in hot spot mode.

3. Setup Serial Port. In the Communication/Advanced tab select “Serial port as” parameter as Terminal. Click “Save Setting” button and wait until finish.




Figure 11. JLink LTE Advanced tab

4. Reboot device. In the Administration/Management tab click “Reboot” button and wait until reboot.




Figure 12. JLink LTE Administration Management tab

5. Setup Router. In the Setup/Router tab select following parameters “NTRIP Client” as Source and “Serial port” as Destination. Click “Save Setting” button and wait until finish.




Figure 13. JLink LTE NTRIP Data Router tab

6. Setup NTRIP Client. In the Services/ NTRIP tab set following parameters: “Server name/address”, “Port”, “User”, “Password” .





Figure 14. JLink LTE NTRIP configuration tab

Click “Save Setting” button and wait until finish.

Click “Update” button and select “Mount-point” .

Click “Save Setting” button and wait until finish. Detailed connection status you can check in Status/NTRIP tab:



JLink LTE Status NTRIP tab

7. Connect Serial Port. se any application to connect serial port of JLink LTE with following parameters:

- Baudrate 115200
- Parity none
- Data Bits 8
- Stop Bits 1
- Handshake hardware

## ...Setup JLink LTE to provide RTK data received via UHF channel (in Satel mode) to Serial Port

The following are the steps of configuration of JLink LTE:

1. Connect to JLink LTE via web interface as described above.

2. UHF configuration in Satel mode:

In the Communication/UHF Int. tab:

- select operating frequency or add new frequency to the list
- select Protocol type Satel
- select channel bandwidth (spacing) either 25.0 or, 20.0, or 12.5 kHz
- verify FEC (Forward Error Correction) state is correct




Figure 15. JLink LTE UHF parameters configuration tab

In the Communication/Power Management tab activate the UHF interface:




Figure 16. JLink LTE Power Management tab

Detailed connection status you can check in Status/UHF int. tab




Figure 17. JLink LTE UHF Int. Status tab

## 3. Setup Serial Port

In the Communication/Advanced tab select “Serial port as” parameter as Terminal.

Click “Save Setting” button and wait until finish.




Figure 18. JLink LTE Advanced tab

4. Reboot device

In the Administration/Management tab click “Reboot” button and wait until reboot.




Figure 19. JLink LTE Administration Management tab

5. Setup Router

In the Setup/Router tab select following parameters “UHF Modem” as Source and “Serial port” as Destination.

Click “Save Setting” button and wait until finish.




Figure 20. JLink LTE UHF Modem Router tab

6. Connect Serial Port

Use any application to connect serial port of JLink LTE with following parameters:

- Baudrate 115200
- Parity none
- Data Bits 8
- Stop Bits 1
- Handshake hardware

## ...Configure TRIUMPH-2 and JLink LTE to provide TRIUMPH-2 services through Internet

In this configuration JLink LTE will share its internet connection (established by GSM interface) with TRIUMPH-2 connected to JLink LTE as a WiFi client.

The following are the steps of configuration of JLink LTE:

1. Connect to Jlink LTE via web interface.
2. GSM configuration

In the Communication/GSM tab. Set the APN parameters (if necessary) and insert the SIM card to its slot(SIM card must by provide Static IP).

In the Communication/Power Management tab activate the GSM interface and wait for registering in the network and Internet access availability. Detailed connection status you can check in Status/GSM tab.




Figure 21. JLink LTE GSM configuration tab

### 3. Setup WiFi configuration

In the Communication/WiFi tab click on “Set AP mode” button to switch the in-

terface to the AP mode and set following AP parameters: SSID(WiFi Acces point-name), Protection(WPA2) and Security passphrase(“password”).

In theCommunication/Power Management tab turn the WiFi interface on.

Detailed connection status you can check in Status/WiFi tab.

Here JLink LTE provides port forwarding mechanism from internet (GSM interface) to WiFi clients.

Port forwarding mechanism works in a following way: JLink LTE receives data from internet and redirects it to its WiFi clients. Data packets received by 1110-1119 ports will be redirected to Wi-

WiFi client which IP address is 10.1.10.110. Data packets received by 1120-1129 ports will be redirected to WiFi client which IP address is 10.1.10.120.

To receive redirected data of JLink LTE the Triumph2 unit should be connected to JLink LTE through

WiFi interface and TRIUMPH-2’s IP address should be set 10.1.10.110 or 10.1.10.120. (the default gateway is 10.1.10.1).




Figure 22. JLink LTE WiFi configuration tab

TRIUMPH-2 configuration steps are the following:

1. Connect TRIUMPH-2 to PC via USB or Blue-tooth interface and start NetView.
2. Click Connection, select the connection using port, specify the COM port the receiver is connected to. Click Connect to connect to the receiver.




Figure 23. NetView connection tab

3. Select the receiver from the list of the connected receivers and click Parameters/Networking/Server, to setup Service port.

Set the TCP/FTP parameter: TCP Port (1125).

Set the TCP/FTP parameter: TCP Output Base Port (1120).

Click Apply.




Figure 24. NetView Server tab

4. Select the receiver from the list of the connected receivers and click Parameters/Networking/WLAN, to setup the WiFi connection.

Set the following IP parameters: WLAN Receiver IP Address(10.1.10.120), WLAN Default Gateway (e.g, 10.1.10.1), and WLAN Network Mask (e.g, 255.255.255.0).

Set the AccessPoint parameters: WLAN Access Point ID (enter SSID of JLink LTE), WLAN AP mode(wpa).

Set the WPA parameter: WLAN WPA Passphrase (enter passphrase of JLink LTE).

Set the WLAN Mode to on Click Apply.




Figure 25. NetView WLAN configuration tab

After Restating the device you can check WiFi connection on web interface Status/WiFi tab of web interface of JLink LTE.




Figure 26. JLink LTE WiFi status tab

Now TRIUMPH-2 can provide services through Internet by 1120-1125 port.

# SPECIFICATIONS

## 4G cellular module

4G LTE Mini Card (option 1)	LTE, DC-HSPA+, HSPA+, EDGE, GPRS, GSM and CDMA networks
Technology:	
LTE	Bands: 1 (2100 MHz), 3 (1800MHz), 7 (2600 MHz), 8 (900 MHz), 20 (800 MHz) Data Rates: Category 3 Downlink 100 Mbps (20 MHz bandwidth), 50 Mbps (10 MHz bandwidth) Uplink 50 Mbps (20 MHz bandwidth), 25 Mbps (10 MHz bandwidth)
UMTS (WCDMA), HSDPA, HSUPA, HSPA+,DC-HSPA+	Bands: 1 (2100 MHz), 2 (1900 MHz), 5 (850 MHz), 6 (800 MHz), 8 (900 MHz) Data Rates: HSPA+ rates Downlink up to 42 Mbps (category 24) Uplink up to 5.76 Mbps (category 6)
GSM, GPRS, EDGE	GSM 850 (850 MHz), EGSM 900 (900 MHz), DCS 1800 (1800 MHz), PCS 1900 (1900 MHz) Data Rates: EDGE throughput up to 236 kbps
4G LTE Mini Card (option 2)	LTE, DC-HSPA+, HSPA+, EDGE, GPRS, GSM and CDMA networks
Technology:	
LTE	Bands: 2 (1900 MHz), 4 (AWS) (1700/2100MHz), 5 (850 MHz), 13 (700 MHz), 17 (700 MHz), 25 (1900 MHz G Block) Data Rates: Category 3 Downlink 100 Mbps (20 MHz bandwidth), 50 Mbps (10 MHz bandwidth) Uplink 50 Mbps (20 MHz bandwidth), 25 Mbps (10 MHz bandwidth)
CDMA (EVDO Rel. 0 and Rel.A)	Bands: BC0 (Cellular 800 MHz), BC1 (PCS 1900 MHz), BC10 (Secondary 800 MHz) Data Rates: CDMA IS-856 (1xEV-DO Release A) Up to 3.1 Mbps forward channel Up to 1.8 Mbps reverse channel CDMA IS-2000 Up to 153 kbps, simultaneous forward and reverse channels
UMTS (WCDMA), HSDPA, HSUPA, HSPA+,DC-HSPA+	Bands: 1 (2100 MHz), 2 (1900 MHz), 4 (AWS 1700/2100 MHz), 5 (850 MHz),8 (900 MHz) Data Rates: HSPA+ rates Downlink up to 42 Mbps (category 24) Uplink up to 5.76 Mbps (category 6)
GSM, GPRS, EDGE	GSM 850 (850 MHz), EGSM 900 (900 MHz), DCS 1800 (1800 MHz), PCS 1900 (1900 MHz) Data Rates: EDGE throughput up to 236 kbps

## UHF/VHF Radio (optional)

Frequency Range	406-470 MHz/138-174 MHz
Channel Bandwidth	25/20/12.5/6.25 kHz
Modulation	DBPSK/DQPSK/D8PSK/D16QAM/4FSK/GMSK
Transmitter Output Power	1W (+30 dBm)
Communication Mode	Half duplex, simplex, repeater

## ISM Radio (optional)

Frequency Range	902-928 MHz (USA)/ 915-928 MHz (Australia)/ 868-870 MHz (EU) with 25/12.5 kHz CS
Modulation	GMSK
Data Rate of Radio Interface (USA/Australia)	64000 bps
Data Rate Radio Interface (EU)	9600 bps
Transmitter Output Power	1W (+30 dBm)
Communication Mode	Half duplex, simplex, repeater

## Beacon Receiver (optional)

Frequency Range	283.5- 325 kHz
User Data Rates	50, 100, 200 bps (manual or Auto selection)
Sensitivity	1.5 mV/m for 6 dB SNR (200 bps)

## GNSS Receiver

Tracking Channels	GPS/GLONASS L1
Signals Tracked	C/A Code
Cold / Warm Start	42 / 30 seconds
Sensitivity for Reacquisition	- 161dBm

## Communication Ports

Wi-Fi 2.4 and 5 GHz (IEEE 802.11 a, b, g, n, d,e,i)
Full-duplex 10BASE-T/100BASE-TX Ethernet port
Bluetooth 4.1 Compliance and CSA2 Support Dual-Mode Bluetooth and Bluetooth LE
High Speed USB 2.0 configurable as Device or Host port
MicroSD card slot (fully sealed)

## Environmental

Enclosure	aluminum, IP67
Color	Two-tone Gray / Green
Operating Temperature	-40° C to +70° C *
Storage Temperature	-40° C to +85° C **
Humidity	100% condensing
Weight	468 g / 970 g
Power Supply Voltage	+5.5...36V without battery charging, 4Amax +12...34V when the battery is charged, 3.6Amax
Battery (optional)	One embedded, 7.2V, 5850 mAh

\* The operating temperature of Li-Ion batteries is -20 ° C to +45° C

\*\* The storage temperature range of Li-Ion batteries is -20 ° C to +60° C

## Pinout of JLink LTE power and communication port

Pin #	Signal Name	I/O	Description	Pin #	Signal Name	I/O	Description
1	TX+/RTS_OUT	O	Transmit Data positive line (RS-422) / Request to Send (RS-232)	14	USB0_VBUS	PWR	Power line (USB)
2	RX+/CTS_IN	I	Receive Data positive line (RS-422) / Clear to Send (RS-232)	15	USB0_ID	I	USB0 ID line
3	DTR_OUT	O	Data Terminal Ready (RS-232)	16	ETD-	O	Transmit Data negative line (LAN)
4	USB0_DP	I/O	Data Positive line (USB)	17	ERD-	I	Receive Data negative line (LAN)
5	USB0_DM	I/O	Data Negative line (USB)	18	PWR_IN	PWR	+5.5 to +36 VDC Power Input
6	ELED+	O	LED line (LAN)	19	GND	PWR	Power Ground
7	ETD+	O	Transmit Data positive line (LAN)	20	GND	PWR	Power Ground
8	ERD+	I	Receive Data positive line (LAN)	21	GND	PWR	Power Ground
9	PWR_IN	PWR	+5.5 to +36 VDC Power Input	22	RESERVE	-	Not used. Reserve
10	TX-/TX_OUT	O	Transmit Data negative line (RS-422) / Transmit Data (RS-232)	23	RESERVE	-	Not used. Reserve
11	RX-/RX_IN	I	Receive Data negative line (RS-422) / Receive Data (RS-232)	24	RESERVE	-	Not used. Reserve



Variant 1



Variant 2



Variant 3



Variant 4

- 1- UHF/VHF/ISM Transceiver / Beacon receiver, cellular module, GPS receiver, Bluetooth, WiFi, Ethernet, USB and Serial port.
- 2 - Variant 1 with battery.
- 3 - Cellular module, GPS receiver, Bluetooth, WiFi, Ethernet, USB and Serial port.
- 4 - Variant 3 with battery.

# Safety Warnings

**Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions.**

Clean only with a damp cloth.

Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.

Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

Only use attachments/accessories specified by the manufacturer.

Use only with a pole, cart, stand, or tripod, specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

Unplug this apparatus during lightning storms or when unused for long periods of time.

Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, or has been dropped.

Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, shall be placed on the apparatus.

## Storage Precautions

Always clean the instrument after use. Wipe off dust with a cleaning brush, then wipe off dirt with a soft cloth. Store in a location with a temperature of from  $-40^{\circ}$  to  $+85^{\circ}\text{C}$ , and no exposure to direct sunlight. Use a clean cloth, moistened with a neutral detergent or water, to clean the receiver. Never use an abrasive cleaner, ether, thinner benzene, or other solvents. Always make sure the instrument is completely dry before storing. Dry the receiver with a soft, clean cloth.

## General Warnings

This product should never be used:

- Without the user thoroughly understanding operator's manual.
- After disabling safety systems or altering the product.
- With unauthorized accessories.
- Without proper safeguards at the measuring site.
- Contrary to applicable laws, rules, and regulations.
- The HPT435BT JL receiver should never be used in dangerous environments. Use in rain or snow for a limited period is permitted.

# Warranty terms

JAVAD GNSS electronic equipment are guaranteed against defective material and workmanship under normal use and application consistent with this Manual. The equipment is guaranteed for the period indicated, on the warranty card accompanying the product, starting from the date that the product is sold to the original purchaser by JAVAD GNSS' Authorized Dealers.

During the warranty period, JAVAD GNSS will, at its option, repair or replace this product at no additional charge. Repair parts and replacement products will be furnished on an exchange basis and will be either reconditioned or new. This limited warranty does not include service to repair damage to the product resulting from an accident, disaster, misuses, abuse or modification of the product.

Warranty service may be obtained from an authorized JAVAD GNSS warranty service dealer. If this product is delivered by mail, purchaser agrees to insure the product or assume the risk of loss or damage in transit, to prepay shipping charges to the warranty service location and to use the original shipping container or equivalent. A letter should accompany the package furnishing a description of the problem and/or defect.

The purchaser's sole remedy shall be replacement as provided above. In no event shall JAVAD GNSS be liable for any damages or other claim including any claim for lost profits, lost savings or other incidental or consequential damages arising out of the use of, or inability to use, the product.



900 Rock Avenue, San Jose,  
CA 95131, USA

Phone: +1(408)770-1770  
Fax : +1(408)770-1799

[www.javad.com](http://www.javad.com)  
All rights reserved © JAVAD GNSS, Inc., 2018